



STABILIGRIP

RIGID FLOOR WITH RAIL JOINT

Installation Guide

LEGEND **FLEET SOLUTIONS**

customer@legendfleet.com | 519.688.1043

Things to make sure you have before beginning the installation: rubber mallet, drill, and a 13 mm bit. Also ensure all wall liners are removed prior to installation.

Note: this guide is for a 3-piece floor. Same techniques and process applies to all others - start at the front of the vehicle and work the installation to the back of the vehicle.

1. Remove all D-rings



2. Lay first piece into front of van, firmly putting into place.



3. Join the h-track (rail) joint to the outerfacing edge of the floor.

4. Attach the second floor piece (usually the smallest) to the rail joint - use a rubber mallet so both floor pieces are secured tightly together.



5. Join the h-track (rail) joint to the outerfacing edge of the second floor piece. Use a rubber mallet to firmly secure it to the floor piece.



6. Attach the third floor piece (usually the largest) to the rail joint - use a rubber mallet so both floor pieces are secured tightly together.

