

# LEGEND FLEET SOLUTIONS

## NISSAN NV200 – CHEVY CITY EXPRESS WALL LINER KIT


### INSTALLATION INSTRUCTIONS



#### NOTES:

1. Before commencing, remove all wall liners and “D” Rings already installed in the vehicle.
2. Consult layout PDF and compare vehicle layout allocated Legend.
3. Prepare hardware shown below and have them ready for installation.
4. Wall liners will be installed in the order shown in the instructions.
5. A drill with a Phillips driver is required to install hardware ( **C** ) #8 Screws, shown below.
6. Reinstall all “D” Rings once the wall liner kit installation is completed.

#### Hardware



**A) Retainer**


**B) #8 Screw Cap**

**C) #8 Screw**

**E) 1/4" Flat Washer**

**F) M6 Bolt**

# NISSAN NV200 – CHEVY CITY EXPRESS WALL LINER KIT



ITEM NO.	PART NUMBER	DESCRIPTION	QTY.
1	534-114-2613	GREY REAR PANEL DRIVER SIDE NISSAN NV200	1
2	532-xxx-6541	FLOOR NISSAN NV200	1
3	535-114-2613	GREY CEILING PANEL NV200	1
4	SCREW CAP	SCREW CAP	52
5	SCREW	SCREW - PHIL. PAN HD #8X.75 SELF DRILLING	85
6	534-114-2613	GREY REAR PANEL PASSENGER SIDE NISSAN NV200	1
7	533-114-2613	GREY SLIDING UPPER DOOR PANEL PASSENGER SIDE NV200	1
8	533-114-2613	GREY REAR LOWER DOOR PANEL PASSENGER SIDE NV200	1
9	533-114-2613	GREY REAR LOWER DOOR PANEL DRIVER SIDE NV200	1
10	RETAINER	RETAINER- BLACK NYLON	50
11	533-114-2613	GREY SLIDING UPPER DOOR PANEL DRIVER SIDE NV200	1
12	533-114-2613	GREY SLIDING LOWER DOOR PANEL DRIVER SIDE NISSAN NV200	1
13	533-114-2613	GREY SLIDING LOWER DOOR PANEL PASSENGER SIDE NISSAN NV200	1
14	537-151-1010	CEILING SILL "B" NISSAN NV200	1
15	537-151-1010	CEILING SILL "A" NISSAN NV200	1
16	533-114-2613	GREY REAR UPPER DOOR PANEL PASSENGER SIDE NV 200	1
17	533-114-2613	GREY REAR UPPER DOOR PANEL DRIVER SIDE NV 200	1
18	538-151-1010	REAR FLOOR SILL NV200	1
19	536-151-1010	FLOOR SILL PASSENGER SIDE NV200	1
20	536-151-1010	FLOOR SILL DRIVER SIDE NV200	1
21	HEX BOLT	HEX BOLT M6 X 20	4
22	FLAT WASHER	Flat Washer 1/4"	4

Note: Model may differ depending if the vehicle purchased came with an OEM partition or not.

## Driver Side Wall Liner Installation

ITEM 1  
REAR DRIVERS  
SIDE PANEL

TAPE


\*TAB

ITEM 11  
FRONT UPPER  
DRIVERS SIDE  
DOOR PANEL

FRONT

REAR

ITEM 12  
FRONT LOWER  
DRIVERS SIDE  
DOOR PANEL




A

B, C

### Installation completed

\*Note: Fix the left side of the panel with tape to keep it in position, make sure the tab on that edge is pushed inside the door cavity. With the tape holding the panel in position, pull the right side out, like a door, while holding it in position, install hardware (B,C) on the tab.



**1:** Install Item 11 & 12, Front Driver Side Sliding door Panels.

- Align notch and edge of panel with the door handle and the bottom panel cavity edge of the door, fix the left side of the panel with tape to keep it in position, make sure the tab on that edge is pushed inside the door cavity. With the tape holding the panel in position, pull the right side out, like a door, while holding it in position, install hardware (B,C) in the holes of the tab on the left side screwing them into the side of the door. Close the panel on the door and align it with the door handle profile.
- Install hardware (B,C), in the holes provided, on the right side of the panel first, working your way to the bottom of the panel.

**2:** Install Item 1, Rear Driver Side Panels.

- Align wheel well edge of the panel with the feature on the vehicle and to the Air vent grill; position the contour of the panel to the vehicle wall.
- Install hardware (A) and (B,C), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.
- DO NOT SCREW DOWN THE TOP OF THE PANEL, THE HOLES ARE FOR THE TOP SILL HARDWARE.



## Back Door Wall Liner Installation

ITEM 16  
REAR UPPER  
DOOR PASSENGER  
SIDE PANEL

ITEM 8  
REAR LOWER  
DOOR PASSENGER  
SIDE PANEL

ITEM 17  
REAR UPPER  
DOOR DRIVERS  
SIDE PANEL

ITEM 9  
REAR LOWER  
DOOR DRIVERS  
SIDE PANEL




**3:** Install Item 16 and 17, Rear Upper door panels,



**Note:** Rear doors must be closed when installing door panels.

- Align the panels with the door contour; **do not mount tight against the door seals.**
- Install hardware (B, C) on the bottom of the panel first, working your way up the panel to the top.
- Install Item 8 and 9, Rear Lower door panels, Install hardware (A) on the top of the panel first, working your way up the panel to the bottom.

Installation completed




## Passenger Side Wall Liner Installation



\*Note: Fix the right side of the panel with tape to keep it in position, make sure the tab on that edge is pushed inside the door cavity. With the tape holding the panel in position, pull the right side out, like a door, while holding it in position, install hardware (B,C) on the tab.

### Installation completed





**4:** Install Item 7 & 13, Front Passenger Side Sliding door Panels.

- Align notch and edge of panel with the door handle and the bottom panel cavity edge of the door, fix the right side of the panel with tape to keep it in position, make sure the tab on that edge is pushed inside the door cavity. With the tape holding the panel in position, pull the right side out, like a door, while holding it in position, install hardware (B,C) in the holes of the tab on the right side screwing them into the side of the door. Close the panel on the door and align it with the door handle profile.
- Install hardware (B,C), in the holes provided, on the left side of the panel first, working your way to the bottom of the panel.

**5:** Install Item 6, Rear Passenger Side Panels.


- Align wheel well edge of the panel with the feature on the vehicle and to the Air vent grill; position the contour of the panel to the vehicle wall.
- Install hardware (A) and (B,C), in the holes provided, on the bottom of the panel first, working your way up the panel to the top.
- DO NOT SCREW DOWN THE TOP OF THE PANEL, THE HOLES ARE FOR THE TOP SILL HARDWARE.

# Ceiling Liner Installation





- 1:** Install Item 3, Ceiling Panel.
- Align Ceiling panel with the feature on the vehicle in the front, align the light opening to the ceiling light.
  - Align the outside holes at the center of the panel with the threaded holes in the ceiling cross bows and install hardware (E,F); this will align the panel with the ceiling, leave bolt loose until the next step is completed.
  - Bend down the back flange of the panel, push the panel against the ceiling and install hardware (E,F), in the threaded holes provided, tighten the two bolts then tighten the two bolts at the center of the panel.
  - Install hardware (A,B) in the holes provided at the four corners of the panel, push up on the panel first to make it sit against the ceiling crossbow, then install hardware (A,B).



**Installation completed**



**VEHICLE IS UPSIDE DOWN**




## Ceiling Sills Installation





**Z:** Assemble Item 15 (SHOWN ABOVE), with hardware (C) in the holes provided.  
FOR PASSENGER SIDE.

- Assemble Item 14 with hardware (C) in the holes provided.  
FOR DRIVER SIDE
- Install the Sill assemblies on the Driver side as well as on the Passenger side using hardware (C) in the holes provided on the Sills. Push up on the Sill when installing the screws on the ceiling panel.


### Installation completed



# Ceiling Sills Installation Details



## Floor and Floor Sill Installation



**ITEM 19-20 FLOOR SILLS –  
SLIDING DOOR**

**ITEM 2 FLOOR**

**ITEM 18  
FLOOR SILL – REAR DOOR**



**8:** Install Items 2 FLOOR and Items 18, 19, 20 FLOOR SILLS.

- Install floor inside the vehicle.
- Align the floor sills in their proper location with the floor edges and install hardware (C) in the holes provided.

**Installation completed**

